

Enterprise Full Touch Handheld Computer

S20

QUICK
GUIDE



BLUEBIRD



Click here for more information!



IPSi

INTEGRATED
PRODUCTIVITY
SYSTEMS

(844) 477-4911 | www.ipsiscan.com

This user manual is protected by copyright.

Copyright © 2023 Bluebird Inc. All rights reserved.
Bluebird Inc. is the designer and manufacturer of Bluebird handheld mobiles.
This manual and the programs in this device are protected under international copyright laws, and may not be copied, distributed, translated, or removed by any means.

Registered Trademark



BLUEBIRD is an emerging global brand, striving to lead the market in performance and mobility. Their products represent reliability, innovation, and innovative technology. Bluebird is a registered trademark from the global brand of Bluebird Inc. and is copyright protected.

- Bluebird and stylized Bluebird Logo are registered trademarks and symbols of Bluebird Inc.
- Qualcomm® IZat™ is a registered trademark of Qualcomm Atheros, Inc.trademark of Qualcomm Atheros, Inc.
- Adobe® is a registered trademark of Adobe Systems Inc.
- All other trademarks and copyrights are the property of their respective owners.

User’s Guidance

| Device type | User’s guidance |
|-----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Class B Device (Household Information & Communication) | This device has qualified the electromagnetic wave suitable registration and can be used as a household device at a residential area as well as any other areas. |
| Type Registration | This wireless device may cause propagation interference, and so, it cannot be used for life-saving services. |

E-Label

Users are able to access the 'E-Label information' in no more than three steps in a device's menu.
The actual steps are : Settings > System > Regulatory labels

1 Safety Information



1.1 Symbols

This manual uses the following symbols to indicate hazards and additional information.

| Symbol | Name | Description |
|--------|---------|------------------------------------------------------------------------------------|
| | Warning | Indicates situations that could cause injury to yourself or others. |
| | Caution | Indicates situations that could cause damage to your device or other equipment. |
| | Note | Indicates additional information that can help you get the most out of the device. |



Please read this safety precaution information carefully. Failure to follow the information provided may result in fire, electric shock, or other property damage or bodily injuries.

1.2 Device



- Do not press the Power button on the device if the device is wet or do not touch adapter or power cord with wet hands. There is risk of electric shock.
- Do not use your device in an explosive danger zone.
- If your device becomes wet, do not put your device in heaters, microwaves, etc. to dry it. There is a risk of explosion or malfunction.



- Do not scratch the device's touchscreen. Use only your fingers or a compatible pen. Never use an actual pen, or any other sharp object on the touchscreen.
- Although this device is very sturdy, do not drop, hit, bend, or sit on it on purpose. It can be broken.
- Do not modify, take apart, or repair the device. Contact to your customer service center. Failure to do so will void your warranty.
- Do not attempt to modify your hardware or software. It may cause device malfunction and void your warranty.
- You may not be able to use this wireless device in basements, open fields, skyscrapers, or other places where the signal is weak.
- Backup the data and information from your device. Your data, such as ringtones, texts, and voice messages, may be erased during repairs or upgrades.
- Do not paint your device. It can damage your screen or your device's exterior.
- Avoid using or storing this device at extreme temperatures. This device is designed to work at temperatures between -20°C and 50°C (-44°F and 122°F), and humidity level 95%.



1.3 Environment



- Do not use the device while driving or operating heavy machinery. Doing so may result in death or serious injury.
- Do not use the device in locations with combustible goods. Doing so may result in an explosion.



- Do not use the device in dusty or hot locations. Doing so may damage the device.
- Do not expose your device to direct sunlight such as on the dashboard of a car for extended periods of time.
- Do not use the device in humid locations. Doing so may damage the device and void the warranty.
- Do not keep the device close to air conditioner vents. Corrosion within the device may occur due to condensation from changes in temperature.
- Do not allow children to play with the device.

1.4 Charging



- Use only the approved charger. Using an incompatible charger may cause device malfunction or other damage, such as fire.
- Charge the battery at least once a year. If you keep it without charging for a long time, it may cause device malfunction.

1.5 Distraction



In some situations, using your device may distract you and cause serious injuries and damages. For example, avoid talking on the phone or texting while driving or riding a bicycle. It is strictly prohibited by law in some jurisdictions. If you cannot avoid using your device while driving, stop your vehicle or use hand-free kit.

1.6 Frequency Interference




- This wireless device may cause radio frequency interference, so use Airplane mode or turn off the device when prohibited.
- The device emits an electromagnetic fields. It may interfere with your medical devices.
- Do not place credit cards, phone cards, bankbook, and tickets next to the device. The magnetic field of the device can damage their magnetic strips.




2.1 Package Contents

The package includes:

-S20



S20 Device and Battery




Battery

 The illustrations may differ from your actual items.




2.2 Your Device

2.2.1 S20 Front View




2.2.2 S20 Rear View






2.2.3 Top and Bottom

-S20 Top View



-S20 Bottom View




3 Getting Started




3.1 Installing the Cards

3.1.1 Inserting a Nano SIM card


1 Remove the card slot.



2 Insert a micro SIM cards into the slots. Make sure that the gold contacts on the cards are facing down.




3 Insert the card slot on your device.






3.1.2 Inserting a Micro SD Card


- 1 Remove the card slot.



- 2 Insert a micro SD cards into the slots. Make sure that the gold contacts on the cards are facing down.



- 3 Insert the card slot on your device.







3.2 Battery

3.2.1 Installing the Battery

1 Insert the bottom part of the battery into place



2 Push the top section of the battery




3.2.2 Removing the Battery

Push both battery latches to open the battery cover.




Before removing the battery, turn off the power. Failure to do so may cause damage to the device.

1 Press the two battery latches in



2 Pull the battery out





3.2.3 Charging the Battery

- 1 Connect the USB-C cable to the USB-C Cable port. The port is located on the bottom section of the S20 device.
 - The battery charging image appears on the screen.
- 2 Connect the USB-C to A cable to the power adapter and then plug the power adapter into a power outlet.




- When charging a discharged battery, the Charging/Notification LED light turns on about 5 minutes after charging begins.



4.1 Turning the Device On or Off

4.1.1 Turning the Device On

Press and hold the Power button for a few seconds.
The Power button is located on the top section of the S20 device.



4.1.2 Turning the Device Off

1 Press and hold the Power button for a few seconds.

2 Tap **Power off**.








- To turn the screen on or off, press the Power button.
- Registering the accounts without turning on the Wi-Fi may incur extra charges depending on your data plan.



4.2 Using the Touchscreen

Use finger gestures to use the touchscreen effectively.

- ⚠ Do not touch the screen with any sharp objects.
- Do not apply too much pressure to the touchscreen.

| Gesture | Name | Description |
|-------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Tap | Briefly touch an item to open, launch, or select it. |
|  | Zoom in or out | Place two fingers on the screen and spread them apart to zoom in. Pull the fingers together to zoom out. You can also double- tap the screen quickly to zoom in or out. |
|  | Tap and hold | Touch an item or the screen for a few seconds to access more detailed menus or options. |
|  | Swipe | Touch the screen and quickly flick in any direction to scroll through menus or pages. |
|  | Drag | Touch an item or the screen for a few seconds and move your finger around the screen to move the item or move through screens. |




4.3 Using the Home Screen

The Home screen is the starting point for all apps and features. It displays icons, shortcuts, and widgets for apps.





Drag upward from the bottom of the screen. Applications will be displayed on the screen. To view other pages, swipe left or right.





4.4 Connecting to a Wi-Fi Network

Connecting to a Wi-Fi network is an easy way of accessing the Internet. When you are out, you can connect to Wi-Fi networks in public places.

- 1 On the Home screen, tap  >  **Wi-Fi**.
- 2 Make sure to turn Wi-Fi on.
- 3 Tap the network you want to join.
- 4 If necessary, enter the password for the network and tap **CONNECT**.

To disconnect the network connection, turn Wi-Fi off.



Your device periodically checks for and notifies you of available connections. The notification appears briefly at the top of the screen.

4.5 Connecting to a Bluetooth Device

You can connect wirelessly to various Bluetooth-compatible devices, such as phones, computers, headsets, and car kits. You can also send your photos to Bluetooth-compatible phones or to your computer.

On the Home screen, tap  >  **Bluetooth**.

Because devices with Bluetooth wireless technology communicate using radio waves, they do not need to have a direct line of sight. However, they must be within 10 meters (33 feet) of each other, although the connection may be subject to interference from obstructions, such as walls or from other electronic devices.



- Paired devices can be connected to your device when Bluetooth turns on.
- Other devices can detect your device only if the Bluetooth settings view is open.



Do not accept the requests from unknown devices and also do not try to pair with an unknown devices. This helps to protect your device from harmful content.



4.6 Battery Hot Swap

This device optionally supports Battery Hot Swap function.

The Hot swap function refers to changing the device's components without shutting down the system.

- 1 Remove the battery cover.
The screen will be turned off automatically.
- 2 Replace the battery with charged one.
- 3 Insert the battery cover and lock it to attach the device.
- 4 Press the Power button to turn on the screen.

Before using the battery hot swap, press the device power button to turn the device LCD off.

- When using the device for the first time, it is recommended to use the device after charging it in the power on mode for at least 3 hours.
- When turning the device on for the first time, 3 minutes is required before performing battery hot swap.
- After removing the battery used for Hot Swap, replace it with a fully charged spare battery within 2 minutes.
- In case that the battery is not replaced for 10 minutes after removing the battery for Hot Swap, the device will automatically power off to prevent discharge of the hot swap battery. At this time, you need to be careful as data loss may occur.
- Do not replace SIM, SAM, or MicroSD Card while Hot Swap is in progress.



- After swapping the battery, you should insert and lock the battery cover. If not, the screen will not be turned on.

5 Device Specification



Physical Characteristics

| | |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dimensions (W x H x D) | 165 x76.9 x 12.5 mm |
| Weight | 235g |
| Display | 6.0" FHD+ (1080 x 2160) |
| Imager Window | Corning® Gorilla® Glass |
| Touchpanel | Dual mode capacitive touch with stylus or bare or gloved fingertip input or conductive stylus (sold separately), water droplet rejection; finger print resistant anti-smudge coating |
| Backlight | LED backlight |
| Power | Rechargeable Li-Polymer, BOS™ PowerManager for real time battery management; Standard capacity 4000mAh / 15.4 Watt hours; Extended capacity 6000mAh / 23.1 Watt hours; (Optional) Hot Swap battery mode BLE Beacon Battery 4000mAh |
| Hot swap | Supported |
| Expansion Slot | User accessible MicroSD supports up to 2TB |
| SIM / SAM | WWAN SKU Only : 1 nano SIM; 1 eSIM |
| Interface | Rear : 8-pin communication connector Bottom : USB-C 3.1 OTG 2-pin Charging Connector |
| Notification | Audible tone; Multi-color LEDs; Scan LED; Vibration; Haptic Feedback; Multi-color LEDs (Top) |
| Keypad | On-screen keypad and Enterprise Keyboard; power button; volume up/down buttons; dual-action side scan buttons; Dedicated PTT Button; button of trigger handle via Back I/O; Top alert Button |
| Voice and Audio | Dual noise-cancelling microphones; vibrate alert; High-quality Single speaker phone; PTT headset USB-C support; Bluetooth wireless headset support, SWB & FB audio cellular circuit switch voice; HD voice; |
| PTT Hot Key | Supports Dedicated PTT Button |



Performance Characteristics

| | |
|------------------|-------------------------------------------------------------------|
| CPU | Qualcomm QC4490 octa-core 2.4GHz |
| Operating System | Android 13; upgradeable to Android 17 |
| Memory | 6GB RAM / 64GB UFS Flash; 8GB RAM / 128GB UFS Flash (Optional) |

User Environment Characteristics

| | |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Operating Temp | -20°C to 50°C / -4°F to 122°F |
| Storage Temp | -40°C to +70°C / -40°F to +158°F |
| Humidity | 5% to 95% non-condensing |
| Drop Spec | Multiple 5 ft./1.5 m drops to tile over concrete (-10°C to 50°C/14°F to 122°F) per MIL STD 810H Multiple 5.25 ft./1.6 m drops to concrete over operating temp (-20°C to 50°C/-4°F to 122°F) with protective boot per MIL STD 810H; |
| Tumble Spec | 550 tumbles, 1.6 ft./0.5 m; (Rugged boot) 550 tumbles 3.3 ft./1.0 m tumbles optional protective boot |
| Sealing | IP68 and IP65, with battery per applicable IEC sealing specifications |
| Vibration | 4 g's PK Sine (5 Hz to 2 kHz); 0.04g ² /Hz Random (20 Hz to 2 kHz); 60 minute duration per axis, 3 axis |
| Thermal Shock | -40° C to 70° C / -40° F to 158° F rapid transition |
| Electrostatic Discharge (ESD) | +/-15kVdc air discharge +/-8kVdc direct discharge +/-8kVdc indirect discharge |



Communication Options

| | |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| WWAN Radio | Rest of World 5G FR1: : n1/3/5/7/8/20/26/28/38/39/40/41/48/77/78/79 4G : B1/3/5/7/8/18/19/20/26/28/34/38/39/40/41/42/43/48 3G : B1/3/5/8/9/19 2G : 900/1800/850/1900 |
| | America (NA+SA) 5G FR1: : n/2/5/7/12/13/14/25/26/28/29/38/41/48/66/71/77/78/79 4G : B2/4/5/7/8/12/13/14/17/25/26/28/29/38/41/42/43/48/66/71 3G : B/2/4/5/8 2G : 900/1800/850/1900 |
| | Dual SIM/Dual Standby, VoLTE, Gigabit LTE-A, 5G NR Sub-6 (NSA, SA), LTE/NR Carrier Aggregation, supports private networking (LTE/5G) |
| WLAN Radio | IEEE 802.11 a/b/g/n/ac/d/h/i/r/k/v/w/mc/ax; 2x2 MU-MIMO; Wi-Fi™ 6E (801.11ax); Wi-Fi certified; Wi-Fi™ 6E Certified; Dual Band Simultaneous; IPv4, IPv6 |
| WLAN Data Rates | 6 GHz: 802.11ax — 20 MHz, 40 MHz, 80 MHz, 160 MHz — up to 2402 Mbps 5 GHz: 802.11a/n/ac/ax — 20 MHz, 40 MHz, 80 MHz, 160 MHz — up to 2402 Mbps; 2.4 GHz: 802.11b/g/n/ax — 20 MHz up to 286.8 Mbps |
| WPAN Radio | Class 2, Bluetooth v5.2 and Secondary BLE for beaconing within BLE battery |
| Accessories | <ul style="list-style-type: none"> - Single-slot charger (Standard, Extended, Rugged boots) - Single-slot USB/Ethernet charger (Standard, Extended, Rugged boots) - Four-slot charger (Standard, Extended, Rugged boots) - Four-slot Ethernet charger (Standard, Extended, Rugged boots) - Standard / Extended Battery - Four-Slot Battery charger (Charges Standard & Extended Capacity battery) - Vehicle charger - Hand strap - Rugged Case - Fiber tipped stylus - Stylus tether - Soft holster - Wearable Trigger Ring - RFR90x Mount - Pistol-grip trigger handle. - Protective Film |



Please ask your sales representative for the specifications not listed above or for future upgradeable specifications.

6 Troubleshooting



The battery does not charge properly.

- Ensure that your device and the charging cable are connected and the charging LED is functioning correctly.
- If the battery does not charge completely, it may be dead or defective. Contact our service center. (The warranty period for battery replacement is six months.)

The battery life got shorter.

When you use network data or peripheral device such as wireless LAN or Bluetooth that require more power, your device may use more battery than usual. If it happens for an extended period of time, your battery may be dead. Then replace it with a new battery.

I dropped the device in water.

Turn off the device. Place the device in a dry place. Let it dry completely for a considerable period of time, and then turn the device back on. If it does not turn back on, contact our service center.

My device gets too hot to touch.

It is normal for the device to warm up while it is receiving a poor signal, performing an intense workload, or charging. It should cool down if you stop using the device for a certain amount of time. If the problem continues, contact the manufacturer. It may result in a burst battery or fire.

How do I get the repair service?

You can contact your local sales representative or you can send the device via a delivery service to Bluebird's Korean headquarters. When sending the package, make sure you pay for the shipping fee in advance. When the repair is finished, Bluebird will cover the shipping cost.

7 Warranty and Support



Customer support

Before asking for after-sales service, please back up the data on the device. We do not back up data from the products sent to the Customer Service Center. Therefore, we assume no responsibility for loss/deletion of data.

Customer Service Center

#1103, Gplus Kolon Digital Tower 11F,
Digital-ro 26-gil 123, Guro-gu, Seoul, Republic of Korea(08390)

- Fax: +82-2-6499-2242
- Email: rma@bluebirdcorp.com
- Hours: 9:30 a.m. - 6:30 p.m. (GMT Time: +9 Hours)



The center is closed on Saturdays, Sundays, and Korean national holidays.

Registering for After-Sales Service

- We receive the products for our after-sales service through mail, delivery services and hand delivery only in principle.
- If you bought the product from a party other than Bluebird or an authorized Bluebird reseller, you need to register the product before using our after-sales service.
- Please enclose an evidence of purchase or the product receipt for our after-sales service.
- Please enclose your name, telephone number, address and details of the problem for a prompt service.
- You can ask for our after-sales service by contacting your authorized Bluebird dealer or the Customer Service Center in the head office.
- Do not intentionally damage the label on the product.
- A damaged label may result in a disadvantage to the customer.
- When you return the product to Bluebird for service, please put the product in a protective box.
- The warranty will not cover any damage which occurs during delivery. We advise you to use the box and protective cover supplied with the product.
- Make sure to deliver the product in a safe way. Bluebird assumes no responsibility for the loss of the product during delivery.



Charged services

- In the following cases, it will be charged when requesting for after-sales service.
 - Service request due to inappropriate use of the device by the customer
 - Loss of PIN number
 - Use of programs that might affect the program (over-clock, forceful changes in the input of the system, personal developments)
- Faults caused by the customer.
 - Defect due to inappropriate or careless use of the product (dropping, submersion under water, shock, damage, unreasonable operations, etc.)
 - Defect due to a repair or unauthorized technician
 - Defect caused intentionally or by the carelessness of the customer
 - Defect due to the use of fraudulent parts or components
- Other cases
 - Defect due to nature (damage caused by fire, wind, flooding, etc.)
 - Accessories are out of warranty (accessories like battery/charger/cable/adapter, etc. have a warranty of 6 months)
- Regulations for repairs after charged services
 - If the same fault occurs in the part that has been repaired within a 1 month (30 days), the part will be repaired free of charge.



No refunds will be offered in the following situations:

- The product seal has been removed (if applicable).
- The product has been damaged due to careless use by the customer or due to a natural disaster (floods, rain, fire, etc.).
- Loss of product or other components (manual, connecting cables, etc).
- DOA (Dead on Arrival) policy
If your product is DOA (Dead on Arrival), or has malfunction within 30 days of purchase (DOA period), the product will either be exchanged or provided with after-sales service.



Warranty certificate

Thank you for purchasing a product from Bluebird Inc.

- In case of accessories such as batteries, only those that match the sales list managed by the Customer Service Center will be eligible for customer service.
- A repair or an exchange of batteries that does not match the sales list of the Customer Service Center due to the carelessness of the customer will be fully charged.

| | |
|--------------------|-----------------------------------------|
| Name of Product | Enterprise Full Touch Handheld Computer |
| Name of Model | S20 |
| Date of Purchase | |
| Manufacture Number | |
| Place of Purchase | |
| Term of Guarantee | 1 year from purchase |

Warranty information

- Bluebird Inc. (hereinafter referred to as Bluebird) provides the warranty service for its products in compliance with the Bluebird's warranty program.
- Upon receiving a notification on a defect of its product within the range of warranty during the warranty period, Bluebird will repair or replace the defective product according to its warranty policy.
- If the defective product within the range of warranty is not repairable or replaceable, Bluebird shall refund the purchasing price within a designated period from the date of receiving a notice of defect.
- Bluebird assumes no responsibility for repairing, replacement or refund until it receives the defective product from the customer. The replacement shall be equivalent to a new product in the aspect of performance.
- Bluebird products may contain the recycled products, components or materials equivalent to new products in the aspect of performance.
- This warranty is applied to software products only when the programming commands are not executed. Bluebird does not guarantee interruption-free or error-free performance.



BLUEBIRD CUSTOMER SERVICE

Operating Hours

Monday to Friday 9:30 A.M. - 6:30 P.M.
(GMT Time: +9 Hours)
The center is closed on Saturdays, Sundays,
and Korean national holidays.

Customer Service Center

#1103, Gplus Kolon Digital Tower 11F,
Digital-ro 26-gil 123, Guro-gu, Seoul,
Republic of Korea(08390)

Bluebird constantly strives to bring utmost satisfaction to all our customers.